


MECHANICAL THERMOSTAT FZK 011



> Adjustable temperature> High switching capacity> Small hysteresis


> Change-over contact > Clip fixing

The mechanical thermostat is used for controlling heating and cooling equipment, filter fans or signal devices. The thermostat registers the surrounding air and can switch both inductive and resistive loads via snap-action contact. Functionality: The temperature setting on the scale equals to the upper switch point, which means that the NC contact opens. The temperature setting minus switch temperature difference (and tolerances) equals to the lower switch point, which means that the NC contact closes.



Ⅲ HeaterⅢ Filter fan,

Cooling equipment, Signal device



Connection diagram

TECHNICAL DATA

Switch temperature difference	5 K (-3/+2 K tolerance) ¹	
Sensor element	thermostatic bimetal	
Contact type	change-over snap-action contact	
Service life	> 100,000 cycles	
Min. switching capacity	10 mA	
Max. switching capacity, NC	AC 250 V / AC 120 V, 10 (4) A ² DC 30 W	
Max. switching capacity, NO	AC 250 V / AC 120 V, 5 (2) A ² DC 30 W	
Max. inrush current	AC 16 A for 10 s	
Connection	4-pole terminal, clamping torque 0.5 Nm max.: rigid/stranded ³ wire 2.5 mm ² (AWG 14)	
Mounting	clip for 35 mm DIN rail, EN 60715	
Casing	plastic according to UL94 V-0, light grey	
Dimensions	67 x 50 x 38 mm	
Weight	~ 0.1 kg	
Fitting position	variable	
Operating/Storage temperature	-45 to +65 °C (-49 to +149 °F)	
Operating/Storage humidity	< 90 % RH (non-condensing)	
Protection type	IP20	
Approvals	UL File No. E164104, EAC	

¹ If the Normally Closed contact is used, the switch temperature difference could be reduced by connecting terminal "N" (RF heating resistor). It causes the thermal feedback which is subject to surrounding conditions and thus has to be determined for each individual application.

² Switching of resistive load (switching of inductive load)

³ When connecting with wires, wire end ferrules must be used.

Important note: The contact system of the regulator is subjected to environmental influences, thus the contact resistance may change. This can lead to a voltage drop and/or self-heating of the contacts.

Operating voltage	Setting range
AC 230 V	+5 to +60 °C
AC 230 V	+40 to +140 °F
AC 230 V	-20 to +35 °C
AC 120 V	+40 to +140 °F
AC 120 V	+5 to +60 °C
	AC 230 V AC 230 V AC 230 V AC 230 V AC 120 V



Heater

Thermostat F7K 011






Thermostat

FZK 011

e.g. Signal device



Thermostat

Examples of connection